

EnviroNize® ULV



Strong injection and ultra-low volume spraying function ensures the penetration and diffusion to fine areas.



Care | Use



1. Fill the **Anolyte Tank** with **EnviroNize® Disinfectant** solution.
2. Adjust the settings using the “Adjustable Settings” valve to desired setting.
3. Apply **EnviroNize® Disinfectant** solution within recommended distance for each setting.

End of Day Maintenance (After Use)



AFTER USE (end of day) empty **EnviroNize® Disinfectant** solution back into the **EnviroNize® Disinfectant** container.



Partially fill the **ANOLYTE TANK** with clean potable water (hot preferred).



Reattach the **ANOLYTE TANK** to the **EnviroNize® ULV** to prepare for the end of day **FLUSHING STEP**.



Flushing Directions: Fully open the valve, run **EnviroNize® ULV** for 30 seconds to clear any granules which may lodge in the spray orifices.

After flushing has been completed empty remaining water used for flushing from the tank reservoir, replace the cap and store the ULV until ready to re-use.

ITEM	DESCRIPTION	CASE WEIGHT	UPC CODE	PACK SIZE	CASES FOR PALLET
ENVULVFOG	CORDED EnviroNize® ULV Sprayer Strong injection and ultra-low volume provide ultimate solution deployment	10.0 lbs 4.54 kg	N/A	1	N/A
ENVULV-TKN	3 Litre Extra Natural Solution Reservoir	1.5 lbs 0.68 kg	N/A	6	N/A



Distributed by **EnviroNize®**
 11-1673 Richmond St. PMB 110, London, ON, Canada N6G 2N3
 877.432.8548 | www.environize.ca | www.environize.us

