

## Onsen Egg Processing Machine User Guide

### 温泉蛋烹调机使用手册

- 1. Fill the eggs into basket provided (1-30 eggs).**  
將蛋放入已提供的籃子內（1-30 個）。
  - 2. Place the basket with eggs into the machine.**  
將籃子放入機器內。
  - 3. Fill up the machine with room temperature water until the level indicated.**  
把清水裝入機內至所指示的水位。
  - 4. Put the cover on and then press button I then press button II. LED light will turns red indicating the machine has started process.**  
把蓋子蓋好，接著按 I 鍵然後按 II 鍵。當 LED 轉紅，表示機器已開始運作。
  - 5. LED light will turns green when it's ready along with 30 seconds buzzer. At this moment, Onsen egg is ready to be served.**  
當運作完畢，LED 燈會轉綠。這時，溫泉蛋就完成了。
- **Please leave the cover off while keeping warm.**  
保溫時請不要把蓋子蓋上。
  - **If you use grade C or smaller egg and find the egg yolk is slightly over cooked, please do not put the cover on when the machine is processing.**  
如果用的是 C 蛋或更小的蛋而且發現蛋黃有些許過熟，請不要在機器運作時把蓋子蓋上。
  - **Please bear in mind that the freshness and the size consistency of the egg will affect the result.**  
請時刻記得蛋的新鮮度和大小的一致性會影響溫泉蛋的成果。
  - **You may put the cooked Onsen eggs into the refrigerator or ice water if you wish to serve cold.**  
如果想要提供冰冷的溫泉蛋，您可以把煮好的溫泉蛋放入冰箱或冰水。
  - **This machine require a minimum 6.5 ampere electric current to ensure the machine function properly, therefore it is suggested to use a single 13 ampere socket point which IS NOT shared with other machines. Please do also ensure that the 13 ampere electric current IS NOT looped through multiple sockets.**  
這台機器需要最少 6.5 安培（TC-50）；8.5 安培（TC-100）的電流來保持正常運作，因此建議使用不與其他機器公用的單個 13 安培的插座。另也請確保這 13 安培的電流沒有環路至多個插座。