

ENVIRO BOOST™

NATURE INSPIRED
INSPIRÉ PAR LA NATURE

LAUNDRY DEEP CLEAN
NETTOIE LES VÊTEMENTS EN PROFONDEUR

pH 10-12



POWERHOUSE Washing Agent



EnviroBOOST™, is electrochemically activated aqueous media which has no detrimental effects on water systems.

EnviroBOOST™, an environmentally friendly washing agent, is an attractive alternative to conventional laundry detergents because it removes soil efficiently from polyamide 6.6 fabric.

Soil removal plays a vital role in caring for fabrics and effective soil removal contributes to maintaining the fabric in a good condition for prolonged use. Dirt that has been rubbed into the fabric causes an increase in the abrasion of the yarns, which eventually causes the fibres to break and damages the fabric.

Insoluble soils such as grease, oil, or film may bind to the fabric by physical attraction. Water alone cannot remove insoluble soils and special materials or solutions such as **EnviroBOOST™** are necessary to assist in the removal process.



PHOSPHATE FREE - because less is so much more!

EnviroBOOST™, a phosphate-free detergent which promotes **Green Cleaning**, significantly assists in keeping wastewater treatment plants clean. Phosphate-free detergents are nontoxic and are biodegradable detergents.

EnviroBOOST™, removes soil efficiently from polyamide 6.6 fabric. **EnviroBOOST™**, can be used at all stages of laundry both separately and in combination. The laundering of textile fabrics with electrochemically activated water contributes to the greener approach of consumers and manufacturers. **EnviroBOOST™**, is used for preliminary soaking of clothes, or added directly in the washing machine as a booster to removing soil load.



EnviroBOOST™
Applicator

POWERED BY **EnviroNize** ACTIVE PAR
Making things better naturally



Pre-wash Applications

Apply **EnviroBOOST™**, directly to the stain via brush, roller, spray or by hand. Pre-wash treatment using **EnviroBOOST™**, quickly tackles focused marks prior to machine washing before the stain beds in.

Washing Machine Options

Add **EnviroBOOST™**, directly to your washing machine's drum or drawer, saving you from applying the product yourself. This method makes it easier to tackle marks from multiple damaged items or particularly large stains.



DIRECTIONS FOR USE:

SMALL LOADS 1/2 cup
LARGE LOADS 1 cup
HEAVILY SOILED LOADS 2 cups
MIXED WITH OTHER DETERGENT 1/2 cup

ITEM	DESCRIPTION	SIZE	CASE WEIGHT	UPC CODE	PACK SIZE
EEBS2007	EnviroBOOST w/EnviroNizer Airless Pump Fine Mist Sprayer Applicator	185 ml 6 oz	1.75 lbs 0.80 kg	625570100484	6
EEBS2002	EnviroBOOST Phosphate-free Detergent Washing Agent	1000 ml 35.2 oz	16 lbs 7.26 kg	625570900477	6
EEBS2003	EnviroBOOST Phosphate-free Detergent Washing Agent	3785 ml 128 oz	36.2 lbs 16.42 kg	625570100415	4



Made in Canada, Manufactured under License from EnviroNize
 11-1673 Richmond St. PMB 110, London, ON, Canada N6G 2N3
 877.432.8548 | enviroboost@environize.ca
www.environize.ca/enviroboost

